



## ■ Measures and displays for coolant temperature

Coolant (T-Coolant)	Operating mode	Display in Cluster	Power output reduction, Air conditioning	Power output reduction, Engine	Torque converter clutch lockup
115					
116					
117	Component Protection		Start 0 %	Start 0 %	
118	Component Protection		–	From here = clear reduction	
119	Component Protection		–	–	
120	Component Protection		End - 100 %	–	
121	Component Protection			–	
122	Component Protection			–	Active
123	Component Protection			–	Active
124	Component Protection			End @ 90 %	Active
125	Emergency				Active
126	Emergency				Active
127	Emergency				Active
128	Emergency				Active
129	Emergency				Active