

ISTA system version: 4.10.20.15602 Data version: R4.10.20 Programming data: 4.10.21

VIN: WBAEH71070B291233 Vehicle: 6'E63/Coupe/645Ci/N62/AUTO/ECE/LL/2003/09

Int.lev.works: E060-03-12-525 Int.lev.(cur.): E060-11-12-500 Int.lev.(tar.): -

Mileage: -

Code	Description	Mileage	Existent	Class
0093C5	No message (engine data, 0x45) from engine control, SIM receiver, DME-DDE transmitter	304088	No	
S 0187	No communication possible with: Door module	-1	yes	
S 0177	No communication possible with: Satellite, vehicle centre	-1	yes	
002737	DME: EWS3.3 anti-tampering protection	304080	No	
00290A	DME: Active Front Steering torque	304088	yes	
0027A4	DME: EWS3.3 interface engine management-immobiliser	304088	No	
0027EE	No message from instrument panel, DME receiver, instrument panel transmitter	304088	yes	
S 0058	No communication possible with: Active steering	-1	yes	
005149	No message from the power module, receiver EGS, transmitter CAS/PM	304080	No	
005140	No message, receiver EGS, transmitter DME-DDE	304080	No	
00D1E4	Message (steering wheel angle, 0xC4) faulty, receiver ARS, transmitter steering column switch cluster	304088	No	
00D1E5	Message (engine speed, 0xAA) error, receiver ARS, transmitter DME-DDE	304088	No	
005F13	DSC: Brake-pad wear, rear axle, brake pads	304088	yes	
00D368	No message (LWS steering box, 0xC3), receiver DSC, transmitter LWS/RAD	304088	yes	
00D354	No message (torque, 0x0A8), receiver DSC, transmitter DME-DDE	304088	yes	
00D355	No message (torque, 0x0A9), receiver DSC, transmitter DME-DDE	304088	yes	
00D356	No message (torque, 0xAA), receiver DSC, transmitter DME-DDE	304088	yes	
00A0BD	CAS: Output, wake-up line	304088	No	
S 0119	No communication possible with: Instrument panel	-1	yes	
S 0375	No communication possible with: Headunit	-1	yes	
009CBC	LM: Short circuit in a lamp circuit	304088	yes	
S 0078	No communication possible with: Central information display	-1	yes	
00E719	Message (coolant temperature, 0x1D0), receiver IHKA, transmitter DME-DDE	304088	No	
00E716	Message (consumer/load control, 0x3B3) faulty, receiver IHKA, transmitter DME-DDE	304088	No	
00E714	Message (battery voltage, 0x3BE) faulty, receiver IHKA, transmitter DME-DDE	304088	No	
00E718	Message (engine heating current, 0x1B6) faulty, receiver IHKA, transmitter DME-DDE	304088	No	